

INSTALLATION, OPERATION, & MAINTENANCE MANUAL

Quality at Every Turn

Hartzell Air Movement 910 S. Downing Street Piqua, OH 45356-0919

PIQUA :: OHIO

@ 1735 FR1844

*

* *

Contact 1-800-336-3267 L info@hartzell.com

Website

THE HARTZELL DIFFERENCE

Building the highest quality fans in America for generations



QUALITY AT EVERY TURN.

Hartzell Air Movement exceeds the standard in the air movement industry, committed to delivering top-quality, reliable products. And our relationship with our customers, and our knowledgeable, inventive, flexible and hardworking employees are the reasons we've continued and thrived, right here in the USA, for six generations.

Customers choose Hartzell for our:

- Durability and high performance
- Low cost of ownership
- Leadership in performance testing and certification
- Advanced engineering and manufacturing processes
- Innovative design and manufacturing
- Trusted brand name

Experienced Hartzell team to assist you from design to shipping

ISO 9001:2015 Certification AMCA Accredited Laboratory Complete Fans and Blowers Centrifugal Wheels Airfoil Propellers

MEMBER



<u>Hartzell</u>



HARTZELL ADVANTAGES

A LIFETIME OF VALUE

- Industrial fans are field proven, 100% tested, with virtually no incident of return
- Energy efficient designs that provide a lower total cost of ownership

LEADERSHIP IN PERFORMANCE

- Products certified by AMCA that meet DOE recommended efficiencies
- Highly efficient industrial fan designs that are the quietest in the market
- Airfoil shape blades with industry leading measured efficiencies

ADVANCED ENGINEERING & MANUFACTURING

- Proven manufacturing techniques on state of the art equipment in ISO 9001:2015 registered facilities
- Engineering team utilizes the latest design tools in 3D CAD and other modeling software

CREATIVE DESIGN & MANUFACTURING TEAM

- Offering the greatest number of industrial fan design choices
- Building products to meet your rigorous application; no limiting catalog

TRUSTED BRAND NAME

Extensive talent pool bringing over 145 years of knowledge and experience to you

5-YEAR WARRANTY

☐ The industry's first and only manufacturer that stands behind their products for a full 5-years

HARTZELL WARRANTY

LIMITED WARRANTIES, LIMITATION OF LIABILITY, AND LIMITATION OF LIABILITY FOR BREACH OF WARRANTY

NO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS

Hartzell does not warrant that said goods are of merchantable quality or that they are fit for any particular purpose. There is no implied warranty of merchantability and there is no implied warranty of fitness.

The details of the Hartzell warranty can be found at http://www.hartzellairmovement.com/warranty-service



Performance Guarantee

You have high expectations. So does Hartzell Air Movement. We know you demand the most reliable and durable industrial air movement products available, so we're holding ourselves to a higher standard. We're so sure that our products will out-perform industry standards, we're backing that promise with the industry's first five-year warranty. Call your Hartzell Air Movement representative for assistance.

Register for your 5year warranty at https://www.hartzellairmovement.com/warranty-and-parts/five-year-warranty

Register your 5 year warranty
 Download your installation manual
 Order replacement parts



Content

Hartzell Warranty	3
Safety Accessories Warning	4
Introduction	5
Shipment and Receiving	6
Handling	7
Storage	7
Extended Storage	8
Installation	9-10
Startup	11-12
Maintenance	13
Bearing Lubrication	14
Bearing Replacement	15
V-Belt Drives	16
V-Belt Replacement	17-18
Belt & Sheave	19
Installing, Tensioning, & Checking V-Drives	20-22
Motors	22
Vibration	23
Grease Lubrication Schedule	24-27
Troubleshooting	27-28
Installation/Startup Checklist	29
Fan Maintenance Log	30

Safety Accessories, Application, and Use Warning

The safe installation and operation of equipment supplied by Hartzell Air Movement is the responsibility of the system designer, installer, maintainer, and user. Since the application and use of its equipment can vary greatly, Hartzell Air Movement offers various product types, optional safety accessories, and sound performance data per laboratory tests.

Hartzell Air Movement sells its equipment with and without safety accessories, and accordingly, it can supply such safety accessories only upon receipt of an order. The need for safety accessories will frequently depend upon the type of system, fan location and operating procedures being employed.

The proper protective safety accessories to meet company standards, local codes, and the requirements of the Occupational Safety and Health Act must be determined by the user since safety requirements may vary depending on the location and application of the equipment. If applicable local conditions, standard, codes or OSHA rules require the addition of the safety accessories, the user should specify and obtain the required safety accessories from Hartzell Air Movement and should not allow the operation of the equipment without them.

Owners, employers, users, and installers should read **"RECOMMENDED SAFETY PRACTICES FOR USERS AND INSTALLERS OF INDUSTRIAL AND COMMERCIAL FANS"** published by the Air Movement Control Association, International, 30 West University Drive, Arlington Heights, Illinois 60004. A copy of this publication is enclosed with each fan shipped from Hartzell Air Movement, and is available upon request at Hartzell's office in Piqua (937-773-8494).

Please contact Hartzell Air Movement or your local Hartzell representative for more information on product types, safety accessories, and sound performance estimates.

Remember, the selection of safety accessories and the safe installation, application and operation of equipment supplied by Hartzell Air Movement is <u>your</u> responsibility. This warning supersedes all previous editions.



INSTALLATION, OPERATION & MAINTENANCE MANUAL

Introduction

The purpose of this manual is to aid in the proper installation and operation of fans manufactured by Hartzell Air Movement. These instructions are intended to supplement good general practices and are not intended to cover detailed instruction procedures, because of the wide variety and types of fans manufactured by Hartzell Air Movement.

The safe installation and operation of fans is the responsibility of the system designer, installer, maintainer, and user. From the initial system design through the life of the equipment, safety should be a foremost consideration. Some areas, which require some special attention, include system design, layout and construction, fan performance specifications, foundation and installation details, storage procedures, start-up and commissioning procedures, operation, maintenance, and repair.

Handling and installation should always be performed by experienced and trained personnel who are aware of the hazards associated with rotating equipment. Failure to comply with these practices may result in death or serious bodily injury.

Contact your local Hartzell representative for further assistance.

Shipment and Receiving

All equipment shipped from Hartzell Air Movement is prepared for shipment in accordance with the requirements of the commercial carrier and/or any special considerations required by the nature of the product.

The Bill of Lading or Express Receipt is an acknowledgment by the Transportation Company of the receipt in GOOD CONDITION, meeting the above requirements for the shipment covered by our invoice.

Our responsibility for the shipment has now ceased. We will not be responsible for loss or damage when you give the Transportation Company a clear receipt. (Standard conditions of sale are F.O.B. factory, unless other terms have been quoted and purchased).

Thoroughly inspect all shipments as soon as received.

Keep a record of all equipment received, including inspection details and date of receipt, because of the possibility of partial shipments.

If any of the items called for in the Bill of Lading or Express Receipt are short or damaged, do not accept them until the Freight or Express Agent makes a Damage or Short Shipment Notification on your freight bill or express receipt.

If any concealed loss or damage is discovered, **NOTIFY YOUR FREIGHT OR EXPRESS AGENT AT ONCE** and request an inspection. This is absolutely necessary. Unless you do this, the transportation companies will not entertain any claim for loss or damage. If the agent will not make an inspection, then you should make an Affidavit to the effect that you notified the agent on that particular date and the agent failed to show up. This, with your aforementioned documentation, will properly support your claim.

We will assist you in every possible manner in collecting claims for loss or damage, however, this does not make us responsible for collection of claims or replacement of material.

Handling

Handle your equipment with care. Some fans are provided with lifting lugs or holes for easy handling. Others must be handled using nylon straps or well-padded chains and cables, which protect the fan's coating and housing. Spreader bars should be used when lifting large parts.

Axial Fans

Axial fans should be lifted by using straps around the fan housing only. **DO NOT LIFT AXIAL FANS BY THE MOTOR, MOTOR BASE, PROP OR FLANGES.**

Centrifugal Fans

Centrifugal fans are best lifted using one strap under the fan's scroll and another strap around the bearing base. DO NOT LIFT CENTRIFUGAL FANS BY THE FAN SHAFT, WHEEL, FLANGES OR INLET SUPPORT.

Roof Ventilators

Roof ventilators should be lifted by using straps around the fan housing or base only. Spreader bars should also be used to avoid damage to stack caps or hoods. **DO NOT LIFT ROOF VENTILATORS BY THE STACK CAP OR HOOD.**

Storage

If fans are stored for any length of time, they should be stored in a clean, dry location to prevent rust and corrosion. Outdoor storage is not recommended. When outdoor storage is necessary, they should be protected from the elements. Cover the fan inlet and outlet, grease the bearings, and keep motors dry and clean.

Extended Storage

Fans are to be stored in their original containers or equivalent protection and should be kept in a clean, dry, protected warehouse where exercised control over temperature, dust, dew point, shock, and vibration is reasonably maintained.

CONDITIONS

- □ Temperatures: Between 50° F. and 120° F. | Between 10° C. and 49° C.
- □ Maximum relative humidity: 60%.
- Shock or vibration: 2 mils maximum to prevent bearings from brinelling.
 Exceeding this limit will require vibration-dampening material under the units.

Motor bearings (and fan bearings on belt drive units) are to be greased at the time of going into extended storage. Motor shafts (and fan shaft on belt drive units) are to be manually rotated every month and additional grease added, purging some grease from the bearing cavity every six (6) months. *Grease in bearings is to be purged at time of removal from storage, making sure that an ample supply of fresh grease is in each grease cavity. Grease used must be compatible with that already in motor and fan bearings (See Page 24).*

All motors with space heaters are to have the heaters connected if storage conditions exceed 60% relative humidity and/or if temperatures are below 50 degrees F.

Motor windings should be meggered at the time the equipment is put in storage. At the time of removal from storage, the resistance reading must not have dropped more than 50% from the initial reading. Contact Hartzell Air Movement Warranty and Service Department if the motor resistance is less than 50% of the initial reading.

NOTE: Motors in storage may absorb moisture in their windings resulting in a significant loss of insulation resistance. THE APPLICATION OF POWER TO A MOTOR WITH INSUFFICIENT INSULATION RESISTANCE MAY RESULT IN DAMAGE TO THE MOTOR OR OTHER EQUIPMENT.

Storage records complying with the above requirements should be maintained.

If an extended warranty is desired, contact your local sales representative for charges and details.

Installation

Centrifugal Fans should always be mounted to a flat, level, and rigid structure. The fan base should be shimmed and leveled. Gaps between the foundation and fan base should be grouted. This will ensure permanent alignment and a smooth-running, vibration-free fan, as well as minimize maintenance costs. Failure to properly install the fan base can contribute to excessive vibration.

Poured concrete foundations are recommended, wherever practical, for floor mounted fans. If vibration isolators are required, they should be installed between the fan and the foundation. Tighten all mounting bolts securely with lock washers and lock nuts.

Fans mounted off ground level should be rigidly mounted to a structural platform and be placed as near as possible to or over, a solid wall or column. Supports for suspended fans must be cross-braced for live load support to prevent side sway.

For roof mounted fans, place the fan curb panel on the roof curb, level, and then anchor the unit to the curb using lag screws, neoprene washers, and flat washers. It is recommended that stacks be independently mounted to the roof and use guy wires to prevent side sway. **AVOID SUPPORTING A STACK DIRECTLY ON THE FAN FLANGE.**

In both axial and centrifugal fans, inlet and outlet ducts should be independently supported, and never supported by the fan flanges. Flexible duct connections are recommended. These connections will also minimize noise. The independent mounting of stacks and ducts to the fan flanges will assure that the fan will not be subjected to external forces which may twist or deform the fan housing. This also will ensure that the impeller will not strike the housing or cause misalignment of the sheaves and bearings.

It is recommended that access doors be placed in ductwork just ahead of the fan inlet and just downstream from the fan outlet for ease of inspection and maintenance. Access doors in a duct system should never be opened with the fan running, to avoid possible equipment damage and personal injury.

No turns in ductwork should be closer than 2.5 fan diameters away from the inlet or outlet of a fan. Walls or flat surfaces should also not be closer than one fan diameter from the inlet side.

Branch entries into the main duct should be spaced such that they do not enter directly opposite each other. A maximum of 45 degree angle between main branch and entering branch should be used as a guideline. Avoid sudden changes in duct size. Use a 15 degree included angle, or less, in reducing a duct to a fan, and not more than 30 degrees included angle on the discharge. Elbow turns should be kept to a centerline radius of at least one and one-half diameters of the duct.

Electrical connections for the fan motor must be connected by a qualified electrician, conforming to the National Electrical code and local codes and practices. When making electrical connections, the motor must be connected following electrical characteristics as indicated by the motor nameplate, and adhere to the wiring diagram on the motor nameplate or in the motor terminal box. *Motors may fail immediately if improperly connected.* It is also recommended that an overload device to protect the motor be installed between the current supply and the motor. Recommended tolerances for overload devices should be plus 10% of the motor full load amperage rating, including the allowance for the motor service factor.

NOTE: It is common for motors to draw several times full load amperage during startup, for approximately fifteen seconds. Larger sized fans may require twenty seconds or longer.

Startup

- Lock out the primary and all secondary power sources.
- A complete inspection should be made of all ductwork and the fan interior. Make certain there is no foreign material, which can be drawn into or blown through the fan or ductwork. Appropriate protective measures and safety practices should be observed when entering or working within these areas. These measures may include the use of goggles, respirators, or other personal protective devices.
- Make sure the foundation or mounting arrangement and the duct connections are adequately designed and installed per drawings and in accordance with recognized acceptable engineering practices.
- Check and tighten all bolts, fasteners, and set screws as necessary. NOTE: Forces encountered during shipment, handling and rigging can disturb factory settings.
- Check the fan assembly and bearings for proper grounding to prevent static electrical discharge. NOTE: This is especially important when using FRP fans.
- Ensure power and drive components such as motor starter, variable frequency drive, or hydraulic power unit are properly sized, matched, and connected to the fan.
- Check bearings for recommended lubricant and lubrication amount.
- Clearance should be checked between the impeller and fan housing. Spin the impeller to determine whether it rotates freely, without hitting anything, and is not grossly out of balance. NOTE: Prior to shipment, all fans have been thoroughly inspected and have passed stringent operation and balance tests.
- Inspect the impeller for proper rotation for the fan design. Arrows to show direction of rotation and airflow are attached to the fan housings.
- □ Check the belt drive for proper sheave selection and installation. Make sure the sheaves are not reversed (excessive speeds could develop).
- □ Check alignment of drives and all other components.
- Properly secure all safety guards.
- □ Assure that all appropriate warnings have been put in place.
- Secure all access doors to the fan and ductwork.

Confirm all inlet and outlet dampers connected to the fan system are open before powering up the fan.

Restore power and momentarily energize the fan to check the direction of rotation. Listen as the fan coasts to a stop for any unusual noise, identify the source, and take corrective action as necessary.

- Switch on the electrical supply and allow the fan to reach full speed. Check carefully for: (1) Excessive vibration; (2) Unusual noise; (3) Proper amperage, voltage, or power values. If any problem is indicated, SWITCH OFF IMMEDIATELY. NOTE: It is normal for belt drive fans to squeal briefly during startup. If no problems are found, while the fan is running, add grease to the fan bearings until the grease purges from he outer seal.
- □ Lock out power supply. Secure the fan impeller if there is a potential for windmilling. Check carefully for cause of the trouble, correct as necessary, and repeat check list procedure. (Ref. Page 27 Trouble Shooting chart)

NOTE: The fan should not need balancing, as it was balanced at the factory to be within stringent vibration levels before shipment. However, there are several things that may cause vibration, such as rough handling in shipment and erection, weak foundations, and alignments. It is recommended that the vibration levels be checked with a vibration analyzer to verify that the vibration is within levels recommended later in this manual. (See Page 23, Table 1).

- Even if the fan appears to be operating satisfactorily, shut it down after a brief period, lock out the power supply, and re-check startup procedures, as the initial start-up may have loosened the bolts, fasteners, and set screws.
- □ The fan may now be put into operation, however during the first eight hour of operation, it should be closely observed and checked for excessive vibration and noise. At this time checks should be made of motor input current and motor bearing temperatures to ensure that they do not exceed manufacturer's recommendations.
- □ After eight hours of operation, the fan should be shut down and the power locked out. Recheck startup procedures and adjust, as necessary.
- □ After twenty-four hours of satisfactory operation, the fan should be shut down (locked out) and the drive belt tension should be readjusted to recommended tension (See Page 20).

Maintenance

Periodic inspection of all the fan parts is the key to long life and trouble-free fan operation. Frequency of inspection must be determined by the user and is dependent upon the severity of the application. Prepare a maintenance schedule and make sure it is strictly adhered to.

NEVER SERVICE OR ADJUST ROTATING EQUIPMENT WHILE IT IS IN OPERATION. LOCK OUT THE POWER SOURCE BEFORE PERFORMING MAINTENANCE.

REGULAR FAN MAINTENANCE:

- Check the fan impeller for any buildup of foreign material or wear from abrasion. Both can cause excessive vibration which will lead to damage of the impeller and other fan components. Replace the impeller if excessive wear is noticed. Carefully clean the impeller of any foreign material.
- Check V-belt drives for proper alignment, tension, and excessive wear.
- Lubricate the fan bearings per the Hartzell Lubrication schedule.
- Lubricate the motor bearings per the motor manufacturers recommendations for grease type and intervals.
- □ Consult the trouble shooting guide for excessive vibration or noise, insufficient performance, or when the fan does not operate (See Page 27 Trouble Shooting Chart).
- □ Tighten all bolts and setscrews.

For arrangement 8 fans only: Lubricate the coupling per the coupling manufacturers recommendations for grease type and intervals. Also, check for proper alignment.

Bearings and Lubrication

All Hartzell belt drive fan bearings are heavy duty, self-aligning ball or roller type, selected for on the fan size, motor horsepower, and performance, and are re-lubricable for continuous service.

Selection of the correct bearing grease and greasing intervals depends on several factors. Extreme high or low temperatures, dirty or damp surroundings, and excessive vibration exceeding the "fair" levels in Table 1 are all things that will require more frequent greasing or special greases. (Refer to Page 24 for recommended greases and greasing intervals.)

The motor bearings and the fan bearings on the belt drive fans should be greased at regular intervals. Motor manufacturers' greasing instructions and recommendations should be followed closely. Avoid the use of a pressure greasing system which tends to fill the bearing chamber completely. Do not over-grease. Limit the use of hand guns to those with a rating of 40 psi or less. Rotate bearings during lubrication where good safety practice permits.

NOTE: On motors with non-regreasable sealed bearings, no lubrication is required for life of the bearings.

The most frequent causes of bearing failure are not greasing often enough, using incompatible greases or excessive belt tension. Excessive vibration, especially if the bearing is not rotating, will also cause bearings to fail. Bearings must also be protected from water and moisture to avoid internal corrosion.

NOTE: It is typical for some anti-friction bearings to exhibit a running surface temperature in excess of 140 deg. *F.* This surface will be too hot to touch, but is not a cause for alarm.

Bearing Replacement

Fan bearings on belt drive fans should not need to be replaced for many years if the above recommendations are strictly adhered to. However, use the following procedure when bearing replacement is necessary.

PROCEDURE:

- □ Lock out power source.
- Gain access to the fan bearings. On ducted axial flow fans, the fan probably wil have to be removed from the duct system. Remove the bearing cover, if any.
- □ Loosen the belts by shifting the motor.
- Remove the impeller and disconnect the lube tubes.
- Remove the shaft and bearing assembly. Note the position of the bearing shims, if applicable.
- Measure the location of the bearing to the impeller end of the shaft and the bearing spacing.
- Loosen all bearing/shaft setscrews or other locking device.
- Remove bearings (may have to be pressed off the shaft).
- Polish the shaft with fine emery paper (240 Grit or finer) and file the setscrew dimples smooth.
- Install new bearings on the shaft, making sure that the collars are together, (i.e., facing each other on the shaft) and set screws are in line with each other. Lightly seat one setscrew on each bearing to hold in the approximate position from above.
- Mount the shaft/bearing assembly in the fan, on shims, with bolts. Do not tighten yet - snug up only. Loosen the setscrews.
- Center the shaft in the housing (both ends) as closely as possible and shim where necessary. The fan impeller may need to be temporarily installed to get the clearances equal.
- □ Tighten the bearing mounting bolts.
- With a soft-faced mallet, tap the shaft between the bearings while turning the shaft by hand to align the bearing races. The shaft must turn freely. Tighten all bearing setscrews. Spin the shaft again, making sure it turns freely.
- Reinstall the lube tubes.
- □ While rotating the shaft, purge bearings with fresh grease (Ref. Page 24).
- □ Install bearing cover, impeller, and belts, and adjust the motor to get proper belt tension. Also, make sure that the sheaves are properly aligned. (See V-belt drives , Pages 17-19).

Carefully following this procedure will ensure trouble-free service.

V-Belt Drives

V-belts on Hartzell belt drive fans are oil, heat, and static resistant type, and oversized for continuous duty. With proper installation and maintenance, years of operating efficiency can be added to the life span of the V-belt drive.

V-belt drives must be completely guarded before applying power to the fan.

A noisy V-belt indicates the need for attention. V-belt noise can be caused by the slapping of the belts against the drive guard or other obstruction. Check for an improperly installed guard, loose belts, buildup of foreign material in the sheave grooves, or excessive vibration. The cause of excessive vibration should be determined and corrected. **NOTE**: *It is normal for belts to squeal briefly at startup.*

Check belt tension often. Ideal tension is the tension at which the belt will not slip under peak load conditions. Over-tensioning shortens belt and bearing life. Keep belts free from foreign material which may cause slipping. The use of belt dressing is not recommended (See Page 20 for recommended tensioning).

Inspect sheaves often. Keep all sheaves grooves smooth and uniform. Burrs and rough spots along the sheave rim can damage belts. Dust, oil, and other foreign matter can lead to pitting and rust, and should be avoided as much as possible. Badly worn grooves or a shiny groove bottom indicates that the sheave, belt, or both are badly worn. Replace any belts and worn sheaves.

Check the sheave alignment. Sheaves that are not aligned properly cause excessive belt wear and sheave wear.

V-Belt Drive Replacement

Whether you are just installing new belts or a completely new drive, worn bearings, bent shafts, or other components that might cause future problems should be replaced at this time. If installing belts only, check existing sheaves carefully for worn grooves or other damage.

Although alignment is not as critical in V-belt drives as in drive types, proper alignment is essential to long belt and sheave life. **NOTE:** *Loose belts or misalignment can cause fan vibration.*

First, make sure that drive shafts are parallel. *The most common causes of drive misalignment are nonparallel shafts and improperly located sheaves.* Where shafts are not parallel, belts on one side are drawn tighter and pull more than their share of the load. As a result, these belts wear out faster, requiring the entire set to be replaced before it has given maximum service. If misalignment is in the sheave, belts will enter and leave the grooves at an angle, causing excessive belt and sheave wear. (See Page 19, Figure 1).

Shaft alignment can be checked by measuring the distance between the shafts at three or more locations. If the distances are equal, then the shafts will be parallel.

To check the location of the sheaves on the shaft, a straightedge or a piece of string can be used. If the sheaves are properly lined up, the string will touch them at the points indicated by the arrows (See Page 19, Figure 2). Rotating each sheave a half revolution will determine whether the sheave is wobbly or the shaft is bent. Correct any misalignment.

Always use matched belts and never mix new and used belts on a drive. Always replace belts with the right type of V-belt. Install belts correctly. When belts are forced into the sheave with a screwdriver or other wedge, the outer fabric is often ruptured and cords broken. It is well worth the time to move the driver unit closer so the V-belts can be slipped easily into the sheave groove without damage. Shorten the center distance between the driven and driver sheave so the belts can be put on without the use of force. While the belts are still loose on the drive, rotate the drive until all the slack is on one side. Then increase the center distance until the belts are snug. The drive is now ready for tensioning.

Tension the belts as indicated on Page 20. **NOTE:** *Never* "*roll*" or "*pry*" *the belts into the sheave grooves.* This can damage the belt cords and lead to belt turnover, short life, or actual breakage. Moreover, it is both difficult and unsafe to install belts this way. Keep take-up rails, motor base, or other means of center distance adjustment free of dirt, rust, and grit. Lubricate adjusting screws and slide rails from time to time.

Tighten all sheave bolts and setscrews before reconnecting the power. **NOTE:** All sheave bolts, setscrews, and belts should be checked and tightened if necessary after two days of initial operation.

IMPORTANT:

DO NOT INCREASE THE FAN SPEED BEFORE FIRST CONTACTING THE HARTZELL FACTORY. ARBITRARILY SPEEDING UP THE FAN CAN CAUSE MOTOR OVERLOAD, FAILURE, AND POTENTIAL IMPELLER FAILURE.



Sheave and Belt Alignment





Belt tensioning tool





How to check for proper belt tension

Installing, Tensioning, and Checking V-Drives

GENERAL DRIVE TENSIONING GUIDELINES:

- □ Ideal tension at which the belt will not slip under peak load conditions.
- Over tensioning shortens belt and bearing life.
- □ Keep belts free from foreign material which may cause slipping.
- Make periodic V-Drive inspection, tension when slipping.
 The use of belt dressing is not recommended.
- □ Before installing a new set of V-Belts, heck the condition of the sheaves. Dirty or rusty sheaves impair the drives efficiency and abrade the belts, resulting in premature failure. Also, worn sheaves can shorten the belt life as much as 50%.
- Do not use a new or used belt as replacement for a unit of a set. If a belt breaks, a new set of matched belts is necessary. Always replace belts with the same kind as originally provided
- After properly tensioning the belts, double-check to be sure the sheave grooves are correctly aligned, and that all shafting is parallel.

INSTALLATION AND CHECKING METHODS

VISUAL METHOD

- 1. When installing belts, reduce the center distance so that the belts may be places in the sheave grooves without forcing. Arrange the belts so that the top and bottom spans have about the same amount of sag. Apply tension to the belts by increasing the center distance unit belts are snug and have a live springing action when struck with the hand.
- Operate the drive a few minutes to seat the belts in the sheave grooves. Observe the operation
 of the drive under it's highest load conditions (usually starting). A slight bowing of the slack side
 of the drive indicated adequate tension. If the slack inside remains taut during the peak load, the
 drive is too tight
- 3. New drive tension should be checked several times during the first 24 hours of operation, by observing the slack side span.

INSTALLATION AND CHECKING METHODS CONT.

□ TENSION GAGE METHOD

When a tension gage is available and the center of the belt span is accessible, the following method may be used. To determine the pounds force required to properly tension a drive with a belt tensioner, proceed as follows:

- 1. Measure the belt span as shown and calculate the deflection inches using the given equation. Set the large O-Ring for calculated inches of deflection.
- 2. Set small O-ring at O and press down the belt tensioner at center of belt span as shown.
 - On a single belt drive, compress the belt tensioner until the large O-ring is even with bottom of a straight edge placed across the outside edge of the two sheaves.
 - On multiple belt drive, compress the belt tensioner until large O-ring is even with the top of the next belt. Average readings from all belts is the value to use in the tables below.
- 3. Remove tension gage and observe the new position of the small O-ring. Set at the number of deflection pounds for the set number of inches.
- 4. Compare this reading, or the average of several readings in the case of multiple belts, to the new/used values in the tables below for the proper belt cross section. If readings do not fall in this range, readjust the belt tension as described and repeat measurement.

Example:

- 1. Belt span = 64 in. and small sheave is 8 in. pitch diameter with Type B notched belts at 3000 RPM.
- 2. 64 in. / 64 = 1" required deflection.
- 3. Set large O-ring at 1" on gage inch scale.
- 4. Set small O-ring at zero on plunger.
- 5. Press down on belts with gage until large O-ring is even with the next belt, or a straight edge, whichever the case may be. With multiple belts, several readings are needed to get an average.
- 6. Use the pound force reading or average of several readings required for 1" deflecting in the tables below.
- 7. The "B" belt table for 8" pitch diameter small sheave should have a deflection force between 7.3 lbs and 10.9lbs.
- 8. Increase or decrease the tension on belts until the deflection force is between 7.3 lbs and 10.9 lbs

Figure 3						
CROSS	SMALLEST	RPM	BELT DEFLECTION FO			ORCE
SECTION	SHEAVE	DANCE	STD. I	BELTS	NOTCHE	D BELTS
SECTION	DIA. (in.)	HANGE	USED	NEW	USED	NEW
	2.0 - 2.4	1000-2500 2501-4000	-	-	3.3 2.9	4.9 4.3
3V , 3VX	2.65 - 3.65	1000-2500 2501-4000	3.6 3.0	5.1 4.4	4.2 3.8	6.2 5.6
	4.12 - 6.90	1000-2500 2501-4000	4.9 4.4	7.3 6.6	5.3 4.9	7.9 7.3
	4.4 - 6.7	500-1749 1750-3000 3001-4000	- - -	- - -	10.2 8.8 5.6	15.2 13.2 8.5
5V , 5VX	7.1 - 10.9	500-1740 1741-3000	12.7 11.2	18.9 16.7	14.8 13.7	22.1 20.1
	11.8 - 16.0	500-1740 1741-3000	15.5 14.6	23.4 21.8	17.1 16.8	25.5 25.0
	12.5 - 17.0	200-850 851-1500	33.0 26.8	49.3 39.9	-	-
oV	18.0 - 22.4	200-850 851-1500	39.6 35.3	59.2 52.7	-	-

Installing, Tensioning, and Checking V-Drives (REF. Pg 19)

Figure 4

	r		·				
CROSS	SMALLEST	RPM	BELT DEFLECTION FORCE			DRCE	
SECTION	SHEAVE	DANCE	STD. I	BELTS	NOTCHED BELTS		
SECTION	DIA. (in.)	HANGE	USED	NEW	USED	NEW	
	2 26	1000-2500	3.7	5.5	4.1	6.1	
	3 - 3.0	2501-4000	2.8	4.2	3.4	5.0	
	20 10	1000-2500	4.5	6.8	5.0	7.4	
A. AA	3.0 - 4.0	2501-4000	3.8	5.7	4.3	6.4	
	50 70	1000-2500	5.4	8.0	5.7	9.4	
	5.0 - 7.0	2501-4000	7.4	7.0	5.1	7.6	
	3.4 - 4.2	860-2500	-	-	4.9	7.2	
		2501-4000	-	-	4.2	6.2	
B. BX	4.4 - 5.6	860-2500	5.3	7.9	7.1	10.5	
		2501-4000	4.5	6.7	7.1	9.1	
	5.8 - 8.6	860-2500	6.3	9.4	8.5	12.6	
		2501-4000	6.0	8.9	7.3	10.9	
	70.00	500-1740	11.5	17.0	14.7	21.8	
C CY	7.0 - 9.0	1741-3000	9.4	13.8	11.9	17.5	
0.07	0.5 16.0	500-1740	14.1	21.0	15.9	23.5	
	9.5 - 16.0	1741-3000	12.5	18.5	14.6	21.6	
	120 160	200-850	24.9	37.0	-	-	
	12.0 - 10.0	851-1500	21.2	31.3	-	-	
	18.0 20.0	200-850	30.4	45.2	-	-	
	10.0 - 20.0	851-1500	25.6	38.0	-	-	

Motors

The fundamental principle of electrical maintenance is **KEEP THE MOTOR CLEAN AND DRY.** This requires periodic inspection of the motor, the frequency of which depends upon the type of motor and the service.

Periodic checks of voltage, frequency, and current is recommended. Such checks assure the correct frequency and voltage applied to the motor, and yield an indication of the fan load. Comparison of this data with previous data will give an indication of the fan performance. Any serious deviations should be investigated and corrected.

Fractional motors usually have pre-lubricated sealed bearings with no grease fittings and are lubricated for life.

Lubricate integral horsepower motors per the motor manufacturer's recommendations. Lubrication frequency depends on the motor horsepower, speed, and service. Use compatible greases (See Page 24). Do not over grease.

If the motor is totally enclosed fan cooled (TEFC), non-ventilated (TENV), or air over (TEAO), it is recommended that the condensation drain plugs be removed. This is not necessary with motors equipped with automatic drains, which should be left in place as received.

Vibration

Excessive fan vibration can be caused by many things. ALL POSSIBLE SOURCES OF THE EXCESSIVE VIBRATION MUST BE CHECKED OUT AND CORRECTIVE ACTION TAKEN IMMEDIATELY TO CORRECT THE PROBLEM. See the fan trouble-shooting chart (Table 2) for possible causes of excessive fan vibration.

A vibration analyzer will be of great assistance in determining the amount of vibration. The following values give an indication of the fan vibration condition. Vibration readings should be taken on the fan bearings (if possible, on belt drive fans), or motor (on direct drive fans), or on the fan housing of ducted axial type fans. Horizontal, vertical, and axial readings should be taken. The following guidelines are based on AMCA Std. 205, Balance Grade BV-3.

Table 1						
Vibration displacement in peak velocity, inches/sec (mm/s) - Filter out						
Condition	Rigidly Mounted	Flexibly Mounted				
Start Up	0.25 (6.4)	0.38 (8.8)				
Alarm	0.40 (10.2)	0.65 (16.5)				
Shut-Down	0.50 (12.7)	0.70 (17.8)				

NOTE: The fan should not be operated if the vibration levels are at or above the Shut-Down range.

Grease Lubrication Schedule

Lubrication guidelines for horizontal shaft, grease lubricated fan, blower or other high speed rotating equipment. Lubrication guidelines for vertical shaft -- see note below.

Bearing Lubrications: Linkbelt

Lubrication Schedule (Months)* - Spherical Roller Bearing - Solid Pillow Blocks									
Shaft DIA				S	peed (RPI	M)			
onare Birt	500	1000	1500	2000	2500	3000	3500	4000	4500
1" Thru 1 ^{7/16} " (25 - 35)	6	4	4	2	1	1	1	1	1/2
1 ^{11/16} " thru 2 ^{3/16} " (40 - 55)	4	2	1 ^{1/2}	1	1/2	1/2	1/2	1/2	1/2
2 ^{7/16} " thru 3 ^{7/16} " (60 - 85)	3	1 ^{1/2}	1	1/2	1/2	1/2	1/2		
3 ^{15/16} " thru 4 ^{15/16} " (90 - 125)	21/2	1	1/2	1/4					

*Suggested lubrication interval under ideal continuous operating conditions. Lubricate while running, if safety permits, until some purging occurs at seals. Adjust lubrication frequency depending on conditions of purged grease. Use one-half of listed interval or vertical shaft applications or for 24 hour operation. House of operation, temperature and surrounding conditions will affect the lubrication frequency required.

- 1. Lubricate with a high quality NLGI No. 2 lithium-base grease (SEE BELOW)
- 2. Lubricate bearings prior to extended shutdown or storage and rotate shaft monthly to aid corrosion protection
- 3. Any lubrication requirements noted on the general assembly drawing supersede requirements found here.

Lubrication Schedule (Months)* - Ball Bearing Pillow Blocks									
Shaft DIA				S	peed (RPI	M)			
	500	1000	1500	2000	2500	3000	3500	4000	4500
1/2" Thru 1 ^{11/16} " (13 - 45)	6	6	5	3	3	2	2	2	1
1 ^{15/16} " thru 2 ^{7/16} " (50 - 60)	6	5	4	2	2	1	1	1	1
2 ^{11/16} " thru 2 ^{15/16} " (65 - 75)	5	4	3	2	1	1	1		
3 ^{7/16} " thru 3 ^{15/16} " (80 - 100)	4	3	2	1	1				

*Suggested lubrication interval under ideal continuous operating conditions. Lubricate while running, if safety permits, until some purging occurs at seals. Adjust lubrication frequency depending on conditions of purged grease. Use one-half of listed interval or vertical shaft applications or for 24 hour operation. House of operation, temperature and surrounding conditions will affect the lubrication frequency required.

- 1. Lubricate with a high quality NGLI No. 2 lithium-based grease
- 2. Lubricate bearings prior to extended shutdown or storage and rotate shaft monthly to avoid corrosion protection. Any lubrication requirements noted on the general assembly drawing supersede requirements found here.

Relubrication Interval					erating S	peed (R	PM)
Shaft Size Ran	ge	Amt. o	f Grease		Max	RPM	
Inches	mm	Cu. In.	Cu. cm.	6 mos	4 mos	2 mos	1 mo
1 7/16 - 1 1/2	40	0.3	4.9	2400	3600	5000	5500
1 11/16 - 1 3/4	45	0.3	5.0	2200	3300	4500	5000
1 15/16 - 2	50	0.4	6.6	2000	3000	4000	4500
2 3/16 - 2 1/4	60	0.8	12.7	1700	2500	3400	3800
2 7/16 - 2 3/4	65	0.8	12.3	1450	2200	3000	3400
2 11/16 - 2 3/4	70	0.9	14.3	1350	2000	2800	3200
2 15/16 - 3	75	1.2	19.7	1300	1900	2600	3000
3 3/16 - 3 1/4	80	1.7	27.4	1200	1800	2400	2700
3 7/16 - 3 1/2	90	2.3	37.7	1100	1650	2200	2300
3 11/16 - 4	100	3.1	50	1000	1500	1950	2100
4 3/16 - 4 1/4	110	4.2	70	900	1350	1850	1900
4 7/16 - 4 1/2	115	5.5	90.1	840	1250	1700	1800
4 15/16 - 5	125	6.4	105	780	1150	1600	1700
Clean and repack ir	ntervals			5 yrs	3 yrs	2 yrs	1yr

Roller Bearing Units Series P-LB6800

*Suggested lubrication interval under ideal continuous operating conditions. Remove bearing cap and observe condition of used grease after lubricating. Adjust lubrication frequency as needed. Use one-half of listed interval for vertical shaft applications for 24 hour operation. Hours of operation, temperature and surrounding conditions will affect the lubrication frequency required. Clean and repack bearings annually. Remove old grease, pack bearing full and fill housing reservoir on both sides of bearings to bottom of shaft.

- 1. Lubricate with a high quality NLGI No. 2 lithium-base grease.
- Lubricate bearings prior to extended shutdown or storage and rotate shaft monthly to aid corrosion protection.
- 3. Purge or remove old grease when changing lubrication brands or types
- Any lubrication requirements noted on the general assembly drawing supersede requirements found here.

Static Oil Lubrication:

- 1. Use only high quality mineral oil with a VG grade indicated on the customer submittal drawing.
- 2. Static oil level should be at the center of the lower-most roller (do not overfill).
- 3. Complete lubrication change should be made annually.

Note:

- 1. These are general recommendations only; specific manufacturer's recommendations may vary slightly.
- 2. Assumes clean environment, -20°F. to 120°F.
 - A. Ambient temperature greater than 120°F. Will shorten bearing life.
 - B. Under extremely dirty conditions, lubricate more frequently.
- 3. Assumes horizontal mounting configuration. For vertically mounted applications, lubricate twice as frequency.
- Lubrication intervals are based on 12 hr. per day operations at a maximum temperature of 160 F hosing temperature.
 A. For 24 hour per day operation, the intervals shall be cut in half.
- 5. Any type of warranty claim must be accompanied with Maintenance Log and Maintenance Schedule.
- 6. During storage or long term shutdowns Fan shaft bearings are to be manually rotated every month and additional grease added, purging some grease from the bearing cavity every six (6) months. Grease in bearings is to be purged at the time of removal from storage, making sure that an ample supply of fresh grease is in each grease cavity. Grease used must be compatable with that already in fan bearing.
- 7. Refer to Assembly/Inspection worksheet for type grease used when assembled.

<u>Sealmaster -</u>	High Temp: Mobilith SHC 220, Lithium Complex, NGLI #2, ISO 220 synthetic oil viscosity
	Standard Application: Lithium Complex, NGLI #2 ISO 110-120 oil viscosity

<u>Rexnord -</u> High Temp: Exxon/Mobil SHC 100 which is also a NLGI 2 grade grease made with lithium complex base and synthetic oil up to 300F

Standard Application: Exxon/Mobil Ronex MP NLGI 2 grade lithium complex -40F to +225F.

For all other Bearing manufacturers, see Assembly and Inspection Sheet or contact Hartzell

Grease Lubrication Schedule Cont.

Lubricate with a premium quality NLGI 2 or 3 multi-purpose ball bearing grease having corrosion inhibitors, anit-oxidant additives and mechanical stability for high speed operation. The grease should also have a minimum base oil viscosity of 500 SUS at 100° F and be suitable to operate continuously at 225° F. Do not use a heavy, long fibered grease.

The bearings on this fan shaft have been greased at the factory for the following application:

- General Purpose (Shell Oil-Shell Gadas S2 V220 2)
- □ High Temperature (Shell Oil-Aeroshell #22 (-85° F. to 400° F. | -65° C. to 204° C)
- Low Temperature (Shell Oil-Aeroshell #22 (-85° F. to 400° F. | -65° C. to 204° C)
- Extreme Moisture (Shell Oil-Shell Gadas S2 V 220 2)
- Other:_____

(Replaces Shell Alvania Grease EP2)

These units are pre-lubricated (except Series P-LB6800) with a multi-purpose Lithium soap grease. When re-lubricating with greases of different types (especially synthetic soaps or oils), complete flushing is recommended.

The presence of dirt, moisture or chemical fumes around the bearings requires more frequent lubrication. Ambient temperatures below 20° F or above 200° F require special lubricants. Consult the machinery manufacturer for recommendations.

When vibration exceeds 0.15 in./sec., frequent lubrication is required and a need for equipment trim balancing may be indicated.

Fill bearings with lubricant prior to extended shutdown or storage. Rotate the shaft several revolutions each month during idle periods.

Note: It is possible to dislodge the seals on these units if grease is added too fast. It is preferable to use a hand gun or a regulated automatic system.

Vertical Shafts:

For vertical applications more frequent re-lubrication is required. The above re-lubrication interval (and clean and re-pack interval for the Series P-LB 6800 bearings,) should be reduced by half.

Table 2					
FAN TROUBLE-SHOOTING CHART					
PROBLEM	POSSIBLE CAUSES				
Excessive Vibration	 Accumulation of material on impeller Worn or corroded impeller Bent shaft Impeller or sheaves loose on shaft Motor out of balance Impeller out of balance Sheaves eccentric or out of balance Bearing or drive misalignment Mismatched belts Belts too loose or too tight Loose or worn bearings Loose fan mounting bolts Weak or resonant foundation Foundation not flat and level Structures not cross braced System pulsation (DANGER) - Fan operation in a stall Blades at different angles on adjustable pitch fans 				
Horsepower Too High	 Fan speed higher than design Air density higher than design Impeller rotating in the wrong direction Angle set too high in adjustable pitch fans 				
Airflow Too Low	 Impeller rotating in the wrong direction Fan speed lower than design Actual system is more restrictive (more resistance to flow than expected) Dampers or registers closed Leaks or obstructions in duct work Filters or coils are dirty or clogged Inlet or outlet screens clogged Restricted fan inlet or outlet No straight duct at fan outlet Shape elbows near fan inlet or outlet Improperly designed turning vanes 				
Airflow Too Much	 Actual system is less restrictive (less resistance to flow) than expected) Fan speed higher than design Filter not in place Registers, grilles and/or dampers not installed 				
Fan Does Not Operate	 Blown fuses Broken belts Loose pulleys Electricity turned off or not wired properly Wrong voltage Motor too small and overload protector has broken circuit 				

Table 2 (continued)					
	FAN TROUBLE-SHOOTING CHART				
PROBLEM	POSSIBLE CAUSES				
Excessive Noise	 Accumulation of material on impeller Worn or corroded impeller Bent shaft Impeller or sheaves loose on shaft Impeller out of balance Bearing or drive misalignment Mismatched belts Belts or drive misalignment Belts nitting guard Loose or worn bearings Belts oily or dirty Defective or bad bearings Bearings need lubrication Loose bearing bolts Loose fan System pulsation or surge Electrical noises Noise from high velocity air system Registers or grilles too small for application Fan in stall condition (DANGER) Rattle of components in high velocity air stream Leaks in duct work Vibrating duct work 				

It is recommended that the users and installers of this equipment familiarize themselves with AMCA publication #201, "Fans and Systems, and publication #202 "Trouble-Shooting", which are published by Air Movement and Control Association, International, 20 West University Drive, Arlington Heights, Illinois 60004.

Installation/Startup Checklist

Become familiar with the equipment by looking at the fan assembly drawing for special instructions and accessories.

Completed By: _____

Date:

INITIAL FAN CHECK

- Inspect fan for damage
- □ Check foundation, prepare for shims
- □ Shim fan shaft level to 0.002"/ft
- □ Are the bolts tight?
- □ Is the fan is distorted by the foundation and/or ductwork? (Note: Applies to direct or isolation mount)
- Check fan interior for debris and standing water

Fan Impeller

- □ Impeller clearance checked
- □ Impeller overlap checked
- Fasteners tight
- Impeller rotates freely

Springs (if equipped)

- □ Springs adjusted properly
- Flex joints allow movement
- Electrical conduit allows movement

Bearings

- Bearings aligned
- Bearings greased (Note: Rotate while greasing)
- Set screws tight (if equipped)

Lube Lines

Lube lines have been charged with grease prior to connecting to bearings

V-Belts (if equipped)

- V-belt drives aligned
- Sheaves re-tightened
- Belt tension correct
- Motor bolts re-tightened

Couplings (if equipped)

- Coupling aligned
- Coupling gap checked
- Coupling lubricated

Accessories

- Guards installed correctly, do not rub
- □ VIV/damper rotates freely (if equipped)
- Other accessories per drawing

ELECTRICAL COMPONENTS

- Motor wired for proper voltage and starter
- Motor grounded
- Appropriate starter and heaters
- Leads are properly insulated
- Accessories wired per instructions supplied

ENERGIZE

- Energize motor long enough to start assembly rotating, then shut down
- Verify direction on impeller rotation, rewire if necessary (Note: Refer to Impeller section)
- Run the fan up to speed
- Check for excess vibration and listen for unusual noise. Refer to Vibration Guidelines.
- Proceed to grout
- Bearing temperatures should stabilize after a few hours. Less than 200°F (Note: Use sense of smell to identify possible electrical/belt issues)

AFTER ONE WEEK

- Verify bolt tightness
- Verify belt tension and adjust as necessary

WARNING: Electrical power must be locked off. Always observe site specific and regulatory safety precautions.

Fan Maintenance Log

Model Number:

Serial Number:

DATE	COMPLETED MAINTENANCE	PERFORMED BY	COMMENTS

Spare Parts:

Spare parts are not needed for the first year of operation. If spare parts are desired, then it is suggested that a spare motor and impeller be ordered for direct drive fans. For belt drive fans, in addition to the motor and impeller, it is suggested that a spare set of bearings, shaft, sheaves, and belts be ordered.

When ordering spare parts, specify the parts desired, the fan model number, and the fan serial number. Contact your local sales representative for price and delivery.





Performance Guarantee

You have high expectations. So does Hartzell Air Movement. We know you demand the most reliable and durable industrial air movement products available, so we're holding ourselves to a higher standard. We're so sure that our products will out-perform industry standards, we're backing that promise with the industry's first five-year warranty. Call your Hartzell Air Movement representative for assistance.

More than 50 Hartzell representative offices can provide specific performance and installation data to meet your requirements. Call your Hartzell Air Movement representative for assistance. Visit www.hartzellairmovement.com or call 800.336.3267 for the name of your representative.





www.hartzellairmovement.com 800.336.3267

Hartzell Air Movement · 910 S. Downing Street · Piqua, OH 45356-0919 A-160-E May 2020 | Printed in U.S.A.